



DFE-HH Catalogue

Overhead Line Remote Fault Indicator

For Reliable, Secure and Economical Energy System Operation

1. General Description




2. Features

[illegible]

3. Specifications


[illegible]

4. Dimensions



5. Accessories

**Please refer to User's Manual to get the way the installation.*



indicator parameters, do some configuration or reset indicator on site.

**Please refer to FPI-HAND User's Manual.*



**Easy for maintenance crew to check fault*

6. Order Info

Item	Content

